

Restoring RX7000 Box to Factory Defaults

Tools Required:	Parts Required:
<ul style="list-style-type: none">• UK IEC Lead	<ul style="list-style-type: none">• RX box (RX7000)• 24V power supply (PC7001A)

This SPL defines how to restore the RX7000 box (Autopod+/PanaPod) with firmware later than v48 to Factory Defaults" by the use of the local buttons on the box. This will restore all of the parameters, apart from MAC address.

Note : This will NOT work on firmware version 42.

Please read in full before attempting to complete this.

1. Press and hold the **Up** and **Down** buttons together, then power on the unit.
2. As the triple flash starts on the leds, release the **Up** and **Down** buttons.
3. Wait a couple of seconds.
4. Press and hold the **Stow** button for 2 to 3 seconds.

Note : This must be done within 6 seconds of the startup completing or this will timeout

5. The unit will flash the SOS signal, then reboot to defaults if this is done as described.
6. The default IP will now match that present in the Foot Controller. These are 172.16.1.199 for Leg Box and 172.16.1.200 for Foot Box.
7. Further to this, the unit will blink S-O-S i.e. three short, three long, three short before doing the reset which confirms this is happening and allows the user time to abort by pulling the power if this was not intended.